


NO. 0638 CORE hoodie | zip



Description (measured in cm)	S	M	L	XL	2XL	3XL	4XL	5XL	6XL
A: ½ Chest width	51	54	57	60	63	66	70	74	78
E: Front length from high point shoulder	69	71	73	75	77	79	81	83	85
H: Shoulder to shoulder	46	47.5	49	50.5	52	53.5	55.5	57.5	59.5
K: Sleeve length - long	66	67	68	69	70	71	72	73	74
L: ½ upper arm width	19	20	21	22	23	24.25	25.5	27	28.5

How to measure



Tolerance +/- in cm

A	E	H	K	K2	L
1.5	1.5	1.5	1.5	1	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not