


NO. G21020 **GEYSER T-shirt | seamless**



Description (measured in cm)	XS	S	M	L	XL	2XL	3XL
A: ½ Chest width	40	43	46	50	54	58	62
E: Front length from high point shoulder	66	68	70	72	74	76	78
H: Shoulder to shoulder	37	39	41	43	45	47	49
K: Sleeve length - long	18.5	19	19.5	20	20.5	21	21.5
L: ½ upper arm width	16.25	17	17.75	18.5	19.5	20.5	21.5

How to measure



Tolerance +/- in cm

A	E	H	K	K2	L
1.5	1.5	1.5	1.5	1	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not