

# NO. G11004 GEYSER active polo shirt | women



Description (measured in cm)	XS	S	M	L	XL	2XL	3XL	4XL
A: ½ Chest width	45	48	51	55	59	62	65	69
E: Front length from high point shoulder	63	65	67	69	71	73	75	77
H: Shoulder to shoulder	39	40.5	42	44	46	47.5	49	51
K2: Sleeve length - short	21	21.5	22	22.5	23	23.5	24	24.5
L: ½ upper arm width	18.5	19.5	20.5	21.5	22.75	24	25.25	26.5

## How to measure



## Tolerance in cm

A	E	H	K	K2	L
1.5	1.5	1.5	1.5	1	1

The measurements in a product measurement chart refer to measurements made directly on the clothing. Lay the garment out flat on an even surface without stretching it. Take the measurements as shown by the arrows and select the size that fits. Use a tape measure for the best results. The tolerances in the measurement chart are based on when the item is received from ID® and not after washing. We reserve the right to make mistakes and omissions in the chart. You are always welcome to contact us for further guidance on using our product measurement chart at [support@id.dk](mailto:support@id.dk) or tel: +45 97492144